

SIEMENS

SIEMENS

issued by
BenQ Mobile GmbH & Co.OHG
Haidenauplatz 1
D-81667 Munich

BenQ Mobile GmbH & Co.OHG
All rights reserved. Subject to availability.
Rights of modification reserved.
Manufactured by BenQ Mobile GmbH & Co.OHG
under trademark license of Siemens AG

www.siemens.com/s75



Designed for life

S75

Safety precautions	2	Setup	36
Phone overview	4	Organiser	46
Display symbols	6	Extras	48
Getting started	7	Alarm clock	51
Switching on/off, PIN entry	10	Media player	52
General instructions	11	My stuff	53
Security	14	Mobile Phone Manager	56
Text input	16	Customer Care	57
Calling	18	Care and maintenance	59
Contacts	20	Product data	60
Call records	23	Limited Manufacturer's	
Camera	24	Guarantee	62
SMS/MMS	26	Sýnýrlý Üretici Garantisi	63
E-mail	31	SAR	64
WAP push	32	Licence Agreement	65
Voice mailbox/CB services	33	Index	69
Internet	34		

This is a summarised version of the User Guide. The complete version can be found on the Internet at this address:

www.siemens.com/s75

Safety precautions

Information for parents

Please read the operating instructions and safety precautions carefully before use. Explain the content and the hazards associated with using the phone to your children.



Remember to comply with legal requirements and local restrictions when using the phone. For example in aeroplanes, petrol stations, hospitals or while driving.



Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. Keep at least 20 cm/9 inches between phone and pacemaker. When using the mobile phone hold it to the ear which is further away from the pacemaker. For more information consult your doctor.



The ringtones (page 36), info tones (page 42) and handsfree talking are reproduced through the loudspeaker. Do not hold the phone to your ear when it rings or when you have switched on the handsfree function (page 18). Otherwise you risk serious permanent damage to your hearing.



Only use original Siemens batteries (100 % mercury-free) and charging devices. Otherwise you risk serious damage to health and property. The battery could explode, for instance.



Do not look at the LED (e.g. activated infrared port, flash LED) with optical magnifiers because of radiation.

This product complies with IEC/EN 60825-1 "Safety of Laser Products" for LED Class 1M products; such products are safe under reasonably foreseeable operating conditions.



Do not place the phone near to electromagnetic data carriers such as credit cards and floppy disks. Information stored on them could be lost.



Small parts such as the SIM card, sealing stop, lens ring and lens cap can be dismantled and swallowed by small children. The phone must therefore be stored out of the reach of small children.



The mains voltage specified on the power supply unit (V) must not be exceeded. Otherwise the charging device may be destroyed.

The power supply must be plugged into an easily accessible AC mains power socket when charging the battery. The only way to turn off the charging device after charging the battery is to unplug it.



You may only open the phone to replace the battery (100 % mercury-free) or SIM card. You must not open the battery under any circumstances. All other changes to this device are strictly prohibited and will invalidate the guarantee.



Please dispose of unwanted batteries and phones as permitted by the laws in your country.



The phone may cause interference in the vicinity of TV sets, radios and PCs.



Use only Siemens original accessories. This will avoid potential risks to health or property and ensure compliance with all relevant regulations.

Improper use will invalidate the guarantee!
These safety instructions also apply to Siemens original accessories.

As mobile devices offer a range of functions, they can be used in positions other than the head, such as on the body. In this case, separation distance of **1.5 cm** is required.

Bluetooth®

Your phone has a Bluetooth interface. This makes it possible to establish a wireless connection of your phone with a headset of a car kit, or with other Bluetooth-enabled devices.

In order to establish a secure link between the devices and to prevent a third party from

having access to your phone, you should observe the following points:

- The initial connection between two devices, what is called "pairing", should take place in familiar surroundings.
- Both devices must be able to identify themselves once by using a password/PIN. To ensure sufficient security, you should choose a 16-digit number combination for a password that would be difficult to guess (if a PIN has not been assigned).
- An automatic connection acceptance ("connection without confirmation") should only be used in exceptional cases.
- In general, only trustworthy devices should be linked in order to minimize security risks.
- You should restrict the "visibility" of your phone if possible. This will make it much more difficult for unknown devices to establish a connection with your phone. To do this, in the Bluetooth menu, set the option **Visib.to others** of **Always visible** to **Not visible** (page 39).
- The name of your phone is transmitted in a Bluetooth connection. The factory default is the "Bluetooth ID". The first time Bluetooth is activated, or later in the Bluetooth menu, you can change this name (**My BT name**, page 39).
- If Bluetooth is not needed, this function should be deactivated.

Before using Bluetooth accessories, or a mobile phone inside a vehicle, check the vehicle user guide for any limitations on the use of these products.

Phone overview

① Softkeys

The current functions of these keys are shown as **text** / symbol (e.g. ☒).

② Call key

Dial displayed/highlighted phone numbers/names, take calls. In standby mode, show last phone numbers dialled.

③ On/Off/End key

- Switched off: press to switch on.
- During a conversation or in an application: press **briefly** to end.
- In menus: return to standby mode.
- In standby mode:
press and **hold** to switch off the phone;
press **briefly**: switch-off menu.

④ Media player key

Direct key for media player.

⑤ Wildcard key

Key for Internet access unless otherwise preconfigured.

⑥ Centre key



Press the centre key to open the main menu and to start an application or function (page 12).

⑦ Navigation keys

In standby mode:

- Open user profiles.
- Open contacts.
- Open inbox.
- Start the camera.






In lists, messages and menus:

- Scroll upwards/downwards.



During the conversation:


- Open contacts.



- ① **Integrated antenna**
- ② **Loudspeaker**
- ③  **Camera key**
- ④  **Media player activated:**
Play/pause.
Media player deactivated:
Play.
- ⑤  **Volume control**
- ⑥ **Display**
- ⑦ **Infrared interface (IrDA)**
- ⑧  **Ringtone**
 - Press and **hold** in standby mode: switch all acoustic signals on/off (except alarm clock).
 - Press and **hold** on incoming call: switch off ringtone for this call only.
- ⑨  **Key lock**
Press and **hold** in standby mode: activate/deactivate key lock.
- ⑩ **Plug socket**
- ⑪ **Slot for RS MultiMediaCard**



- ① **Car Kit holder**
- ② **Flash/torch**
 Press and hold  key: switch torch on/off.
- ③ **Connection for external antenna**
- ④ **Camera lens**
- ⑤ **Mirror**



Display symbols

Display symbols (selection)



Signal strength



Battery charge level, e.g. 50 %



Contacts



Call records



Internet/Service provider portal



Games



Organiser



Messages



Camera



Extras



Media player



My stuff



Alarm clock



Setup



All calls are diverted.



Ringer (beep) off



Alarm set



Keypad locked



Activated and available



Browser is being connected



IrDA transmission

Events (selection)



SMS memory full



MMS memory full



Phone memory full



No network access



Inbox

Message symbols (selection)



Unread



Read



Sent



MMS notification received

MMS with DRM contents
(page 11)

E-mail forwarded



E-mail with attachment



Voice mail received

Getting started

Your phone's display is covered with a protective film. Remove this before using the phone.




In rare cases static discharge can cause temporary discoloration in the display. However, this will disappear within approx. 10 minutes.


Inserting SIM card/ battery

The service provider supplies you with a SIM card on which all the important data for your line is stored. If the SIM card has been delivered in credit-card size, snap the smaller segment out and remove any rough edges.

- Place the SIM card in front of the slot with the contacts facing downwards. Then push the SIM card fully into the holder using gentle pressure ①. Ensure that the chamfered corner is in the correct position.




- Insert the battery sideways into the phone ②, then press it downwards ③ until it engages.




- To remove, press the retaining tab on the side of the battery, then lift the battery out.

- Insert the battery cover with the retaining lugs underneath the camera lens ④, then press down at the back ⑤ until it clicks into place.



- To remove, lift the battery cover up and off ⑥.




Additional information

Please switch off your phone before removing the battery!


1.8 and 3 volt SIM cards are supported. Please contact your service provider if you have a different card.

RS MultiMediaCard™

- To insert, lay the card in the carrying tray ① (ensure that the chamfered corner is in the correct position). Push the carrying tray with the card into the phone until it clicks into place ②.



- Press the small button ③ to remove (e.g. with a pin). The card tray will pop out a little and you can remove it.




- Before removing the card, call up the Eject card function in the My stuff options menu. This saves data you have not yet saved and avoids losing data.

Charging the battery

Charging

The battery is not fully charged when delivered. Plug the charger cable into the bottom of the phone, plug the power supply unit into a mains power socket and charge for at least **two hours** (for charging via USB, see page 45). Do not interrupt the charging procedure prematurely.



Display when charging is in progress.

Charging time

An empty battery is fully charged after about 2 hours. Charging is only possible within a temperature range of +5 °C to +45 °C. If the temperature rises/falls 5 °C above/below this, the charge symbol flashes a warning. The mains voltage specified on the power supply unit must not be exceeded.

Operating time

The operating time depends upon the respective conditions of use. Extreme temperatures considerably re-

duce the phone's standby time. You should therefore avoid leaving the phone in the sun or on a radiator.

Talktime: up to 300 minutes

Stand-by time: up to 300 hours

Charge icon not visible

If the battery has been discharged fully, the charge icon is not immediately visible when the power supply is plugged in. It will appear after up to two hours. In this case the battery is fully charged after 3 to 4 hours.

Only use the plug-in power supply unit included in delivery!

Display during operation

Charge level display during operation (empty–full):



A beep sounds when the battery is nearly empty. The charge level of the battery is only displayed correctly after an uninterrupted charging/discharging cycle. You should therefore **not remove the battery unnecessarily** and where possible **not terminate the charging process before completion**.

Additional information

The power supply unit heats up when used for long periods. This is normal and not dangerous.

If the battery is removed for longer than 30 seconds, the clock must be reset.

Switching on/off, PIN entry

Switching on/off



Press and **hold** the On/Off/End key.

Entering PIN

The SIM card can be protected with a 4 to 8-digit PIN.



Enter the PIN using the number keys. The characters **** appear in the display to ensure nobody can read your PIN. Correct with **⏪**.

OK

Press the left softkey to confirm. Logging on to the network will take a few seconds.

Additional information

Changing the PINpage 14

Clearing SIM card barringpage 15

Emergency number (SOS)

Only to be used in real emergencies!

By pressing the left softkey **SOS** you can make an emergency call on any network **without** a SIM card and without entering a PIN (not available in all countries).

Switching your phone on for the first time

Time/date

Set the clock correctly once when getting started.



Confirm.



Start entry.



First enter the date (day/month/year), then the time (24 hours, including seconds).



Confirm. The time and date are updated.

Time zones



Select the city in the desired time zone.



Confirm.

General instructions

Standby mode

The phone is in **standby mode** and is **ready for use** when the name of the service provider appears on the display.



Press the On/Off/End key to return to standby mode from any situation.

Receiving signal



Strong receiving signal.



A weak signal reduces the call quality and may lead to loss of the connection. Change your location.

Digital Rights Mgmt. (DRM)

Remember that your phone has Digital Rights Management. The use of downloaded pictures, sounds or applications can be restricted by the suppliers, e.g., copy protection, use for a limited period of time only, number of times it can be used etc.

User guide

The following symbols are used to explain operation:



Enter numbers, letters.



On/Off/End key



Call key



Softkeys



Displays a softkey function.



Press the centre key, e.g., to call up the menu.



Press the navigation key on the side marked with a triangle.



Function dependent on the service provider.

Main menu

The applications are shown with symbols in the main menu:



Call up from standby mode using the centre key.



Select application with the navigation key.




Start application.

Main menu options

Options	Open menu.
Search	List output of the menu.
Big letters	Select one of two font sizes.
Illumination	Set display light brighter/darker.
Eject card	Data backup before removing the RS MultiMediaCard.

Tabs



Switch between the individual tabs.

If an input field is activated on a tab, it is only possible to navigate within the field using the navigation key.

Menu controls

The steps needed to reach a function are shown in a **condensed form** in the user guide, e.g. to display record of missed calls in condensed form:




This comprises the following steps:



Pressing the centre key opens the main menu in standby mode.



Select the record application .



Confirm with the centre key.



Select the function **Calls dialled**.



Confirm with the centre key.

Centre key

The symbol in the centre of the lower line of the display shows the current function when the centre key is pressed.



Main menu



Send



OK, confirm



View



Change



Save



Call



Play



Edit



Record



Insert



Pause



Options



Stop




Camera



Zoom

Standard functions

Functions which appear repeatedly in the options menu are listed here.

Options	Open menu.
Edit	Open the entry to edit.
View	Display entry.
Delete	Delete entry.
New entry	Create new entry.
Send...	Select transmission service and medium for sending.
Print...	Printout on a suitable terminal via IrDA, Bluetooth or USB.
Reply/ Reply to all	The sender becomes the recipient, "Re:" is placed before the subject, and the received text is transferred into the new message.
Save	Store entry.
Save to 	Save recipient in Contacts.
Sort	Set sort criteria (alphabetical, type, time).
Rename	Rename selected entry.
Capacity	Display memory capacity.
Import	Device ready to receive data (vcard, vcal, vnotes) via IrDa or Bluetooth.
Attributes	Display properties of the highlighted object.
Help	Display help text.

Printing via USB

This Mobile Printing Ready product is designed to provide easy printing from mobile phones by connecting the mobile phone with a USB data cable to the printer.

This product follows the guidelines Version 1.0 for PictBridge from Mobile Imaging and Printing Consortium (MIPC).

Highlighting mode

For some applications (e.g. deleting several SMS messages) you can highlight several entries on the tab in order to perform multiple functions at once.

- Options** Open menu.
- Mark text** Activate highlighting mode.



Select entry/entries.



Highlight or remove highlighting.

Additional highlighting functions:

- Options** Open menu.

Mark all	Highlight all entries.
Unmark all	Delete highlighting on all marked entries.
Delete marked	All highlighted entries are deleted.

Security

The phone and SIM card are protected against misuse by several security codes.

Keep these security codes in a safe place where you can access them again if required.

PIN codes

PIN	Protects your SIM card (personal identification number).
PIN2	This is needed to set the charge detail display and to access additional functions on special SIM cards.
PUK PUK2	Key code. Used to unlock SIM cards after the wrong PIN has been entered repeatedly.
Phone code	Protects your phone. Must be entered at the first security setting.



PIN control

The PIN is usually requested each time the phone is switched on. You can deactivate this feature but you risk unauthorised use of the phone. Some service providers do not permit deactivating the control.



Edit.



Enter PIN.



Confirm entry.

Change PIN

You can change the PIN to any 4 to 8-digit number you find easier to remember.



Edit.



Enter **current** PIN.



Confirm.



Enter **new** PIN.



Repeat **new** PIN.

Change PIN2

Proceed as for **Change PIN**.

Chg. phonecode

(Change phone code)

You define the phone code (4-8 digit number) the first time you call up a phone-code protected function (e.g. **Direct call**, page 43). It is then valid for all phone-code protected functions.

Following the third incorrect attempt, access to the phone code and the functions that use it is denied. If this happens please contact Siemens Service (page 57).

Clearing SIM card barrings

If the PIN is entered incorrectly three times, the SIM card is barred. Enter the PUK (MASTER PIN) provided by your service provider with the SIM card in accordance with the instructions. If the PUK (MASTER PIN) has been lost, please contact your service provider.

Preventing accidental activation

Even if PIN use is deactivated (page 10) confirmation is required to switch on the phone.

This prevents the phone from being switched on accidentally, e.g. when carried in a pocket or whilst you are on an aircraft.



Press and **hold**.



Press. The phone switches on.



Press (or no further input) to stop switch-on procedure. The phone does not switch on.

Connection with PCs

You can connect your phone to a PC using IrDA, Bluetooth or a data cable (accessories). The PC program MPM (Mobile Phone Manager) enables you to store data on your PC and, for example, synchronise the Addressbook with Outlook®, Lotus Notes™ and other Siemens phones (including Gigaset). You will find Mobile Phone Manager on the CD-ROM supplied or you can download it from the Internet at:

www.siemens.com/s75

Text input

Text input without T9

Press the number key repeatedly until the required character appears. After a brief interval the cursor will advance. Example:



Press **briefly** once to write the letter **a**, twice for **b** etc.

Press and **hold** to write the number.



Press **briefly** to delete the letter before the cursor, press and **hold** to erase the whole word.



Move the cursor (forward/back).



Press **briefly**: swap between *abc*, *Abc*, *T9abc*, *T9Abc*, *123*.

Press and **hold**: all input variants are displayed.



Press and **hold**: open text input menu.



Press **once/repeatedly**:

.,?!' " 0 + - () @ / : _

Press and **hold**: write 0.



Inserts a space. Press twice = line break.

Special characters



Press **briefly**:

1)	¿	i	_	;	.	,	?	!
+	-	"	'	:	*	/	()
¤	¥	\$	£	€	@	\	&	#
[]	{	}	%	~	<	=	>
	^	`	\$	Γ	Δ	Θ	Λ	≡
Π	Σ	Φ	Ψ	Ω				

1) Line break



Scroll to a character.



Confirm.

Text input menu



Press and **hold**:

Input language, Mark text, Copy/Insert

Text input with T9

"T9" uses various key entries to deduce the correct word.





Activate/deactivate T9.

Writing with T9

It is best if you finish a word without looking at the display.


Simply press the keys where the relevant letter is located **once**.


 /  A blank space or moving to the right ends a word.

Do not use special characters such as Ä. Use standard characters only, e.g. A. T9 will do the rest.

T9 word suggestions

If several options are found in the dictionary for a word, the most probable is displayed first.


 Press. If this word is incorrect, press again.


 Keep pressing until the correct word is displayed.


To enter a word in the dictionary:

Spell Select and enter the word without T9, then **Save**.


Correcting a word

 Move left or right, word by word, until the required word is **highlighted**.


 Scroll through the T9 word suggestions again.

 Deletes the character to the left of the cursor **and** displays a new possible word.

Additional information

 Press **briefly**: swap between: abc, Abc, T9abc, T9Abc, 123. Status shown in top line of the display.

Press and **hold**: all input variants are displayed.

 Press **briefly**: select special characters (page 16).

Press and **hold**: opens text input menu (page 16).

T9® Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,187,480, 5,818,437, 5,945,928, 5,953,541, 6,011,554, 6,286,064, 6,307,548, 6,307,549, and 6,636,162, 6,646,573; Australian Pat. Nos. 727539, 746674, and 747901; Canadian Pat. Nos. 1,331,057, 2,302,595, and 2,227,904; Japan Pat. No. 3532780, 3492981; United Kingdom Pat. No. 2238414B; Hong Kong Standard Pat. No. HK1010924; Republic of Singapore Pat. No. 51383, 66959 and 71979; European Pat. Nos. 0 842 463 (96927260.8), 1 010 057 (98903671.0), 1 018 069 (98950708.2); Republic of Korea Pat. Nos. KR201211B1 and KR226206B1. People's Republic of China Pat. Application Nos. 98802801.8, 98809472.X and 96196739.0; Mexico Pat. No. 208141; Russian Federation Pat. No. 2206118; and additional patents are pending worldwide.

Text modules

 →  → Templates
→ Text modules

Text modules can be stored in the phone for adding to your messages (SMS, MMS, e-mail).

Calling



Enter number (always with area/international dialling code).

◀ A **short** press clears the last digit, a **long** press clears the phone number.



Press the Call key. The displayed phone number is dialled.

Ending a call



Press **briefly**.

Setting the volume



Adjust the volume with the plus/minus keys.

Last number redial



Press **twice**. The phone number **last** called is redialled.

Call from the redial list:



Press **once**; choose phone number.



Dial phone number.

Auto last number redial

Options Open, then **Auto dial**. The phone number is dialled ten times at increasing time intervals.

Reminder

Options Open, then **Reminder**. A beep reminds you to redial the displayed phone number after 15 minutes.

Accepting a call



Press.

Rejecting a call



Press **briefly**.

Additional information

Accept the call before bringing the telephone to your ear in order to avoid ear damage caused by the ringtones.

Handsfree

Options Open, then activate/deactivate **Handsfr**. Always switch off "handsfree talking" before holding the phone to your ear. Otherwise, you will damage your hearing!

International dialling codes



Press and **hold** until a "+" is displayed.

Options Open, then select **Country**.

Call options

Functions which are only available **during** the call are offered in the call menu.

Swapping between 2 calls



Establishing a second connection

Options Open, then Hold.



Select phone number from Contacts or enter it manually. When the connection is established:

Options Open call menu.

Swap Swap between the calls.

Incoming calls during a call

You will hear the "call waiting" tone (page 41) and have the following options:

- **Accept the waiting call in addition to the first**

Swap Accept the call and put the current call on hold.

- **Reject the waiting call**

Reject Reject or use **Divert** to divert to the mailbox.

- **Accept the waiting call and end the current call**



End call.



Accept new call.

End call(s)



Press **briefly**.

Yes

Resume the held call.

No

End all calls.

Conference



You can call up to 5 conference participants one after the other. When the first connection is established:

Options Open, then Hold.



Select phone number from Contacts or enter it manually. When the connection is established:

Options Open, then use **Conference** to join in the held connection. Repeat until all participants are connected.

Ending



All calls in the conference finish simultaneously when the End key is pressed.

Tone sequences (DTMF)

Enter tone sequences (digits) for remote access to an answering machine.

Options Open, then select Send DTMF.

Contacts



You can store up to 5000 entries in this phone directory, with several phone and fax numbers plus additional address details. Five tabs are offered for fast access:

All contacts, Groups, Online status, SIM, Filter



Open Contacts (in standby mode).



Switch between the individual tabs.

Communication



Select contact.



Call selected contact.

Or

Options

Open menu, then **Create message**, to start an Instant Message dialogue.

All contacts

Display all entries stored in the phone or on the SIM card in alphabetical order.

New entry



Confirm **New entry**. The tabs are displayed.



Switch between the individual tabs:

General sett.

First name, surname and important phone numbers. A ringtone, a picture, or video with sound can be assigned to each contact.

Private

General address information and additional communication numbers such as fax and e-mail.

Business

Company information, address, communication numbers.

Person

Personal details such as date of birth, group membership and other notes.

Online status

Contact information for Instant Messaging (page 30).

In the respective tabs:



Select required input fields.



Enter at least one name/company. Enter phone number with dialling code.



Open menu and select **Save**.

Viewing/editing entries



Select required entry.



Open current tab to edit.



Open options menu.

Groups

You are offered 10 different groups to enable you to arrange your contacts clearly.

Editing group attributes



Select group.

Options

Open menu and select **Attributes**.

Adding a contact

Start function in the **All contacts** tab.



Select contact, open **Options** and select **Add to group**. A contact can only belong to one group.

Online status

Display all contacts that have WV addresses (Instant Messages).

SIM

Display contacts on the SIM card.


New entry



Confirm **New entry** and name, enter phone number and select the storage location.

Viewing/editing entries




Select required entry and edit  entry.

Filter

Those entries which match the selected filter criteria are displayed, e.g. those containing a picture.

General functions

Options Different functions are offered depending on the tab and the current situation.

Filter	Only those entries which match the filter criteria are displayed.
Create message	Create a message for the selected contact.
Search IM ID	Search for assigned Instant Message ID.
Internet	The URL assigned to the contact is visited via the WAP browser.
Open	Display "own" phone numbers (e.g. fax) for reference.
Add to 	Store entry in Contacts.
Add to group	Add entry to a group.
Take a picture, Record video, Record sound, etc.	Create picture, video and sound information for a contact from scratch or add from My stuff.
More	See below.

(For standard functions see page 13)

More

Location

Swap entries between the phone memory and the SIM card.

Synchronisatn.

You can synchronise your mobile with an organiser stored on the Internet (**Remote sync.**, page 47).

Capacity

Display memory capacity.

Setup

Set displays in the tabs.

As business crd

Define a selected contact as a business card.

Business card

Establish a contact as your own business card to send to a different GSM-phone.

Import

Set up readiness to receive via IrDA or Bluetooth.

Add more fields

Move SIM card entry to the phone memory. Now all tabs are offered for further entries.

Call records

Phone numbers are stored for easy redialling.



Select and open record.



Select phone number.



Dial phone number.

Up to 500 entries are stored in the records:

Calls missed



The phone numbers of calls that you have received but not answered are stored for call back purposes.



Symbol in the display for a missed call.

Calls received

List accepted calls.

Calls dialled

Access to the last numbers you have dialled.



Fast access in standby mode.

Delete records

Delete records.

Time/charge

Display charges and duration during a call.



→ Time/charge

Last call, All outg. calls, All incoming, Remaining units



Select display and open area.

Options

Open, then **Reset** to reset the setting.

Charge settings

Currency

Enter desired currency.

Personal rate

Enter the currency as well as the charge per unit and time (PIN2).

Account limit

Special SIM cards allow you or the service provider to define a credit limit after which the phone is barred for outgoing calls.

Auto display

Call duration and charges are displayed automatically.

Camera

A camera with flash is integrated in the phone. Use photos/videos as

- wallpaper, logo, screensaver, startup and shutdown animation
- a supplement to contact entries
- an attachment to an MMS or e-mail

Save photos and videos in **My stuff** (page 53) or on the **RS MultiMedia-Card** (page 55).

Activating



Or



with the plus/minus key in standby mode.

The preview image is displayed. In the first line you will see:



Zoom factor



Night mode



White balance



Flash active.

The number of photos that can still be taken in the selected resolution is displayed in the preview image. This number varies considerably depending on the subject matter and how much storage space is required. You will also see an indication of the selected resolution or, if video mode has been selected, there is an indica-

tion as to how much recording time has already been used and how much time is still available.



Switch between the **Take a picture** and **Record video** tabs.

Take a picture



Take a photo.



If necessary, set the zoom factor first.

The photo is saved with a name, the date and the time in the **Pictures** (page 53) folder in **My stuff**. To enter the name, see **Setup** in the options menu.

Image resolution

It is possible to set the quality of the image regardless of the preview image resolution. The best possible resolution is 1280 x 960 pixels.

To take individual wallpaper images you need to set **Wallpaper** as the image resolution in the options.

The resolution may decrease depending on the selected digital zoom.

Record video

The video mode resolution is the same as the preview image resolution.



Start video recording.
A red dot appears in the display.



End video recording.

Video resolution

It is possible to set the quality of the image for a video regardless of the preview image resolution.

The best possible resolution is 176 x 144 pixels.

Flash

If the flash is active it is charged constantly. This reduces the stand-by time.



This symbol flashes when the flash is being charged.

For settings, see options menu. The flash performance depends on the outside temperature and the charge status of the battery. If the temperature is low and the battery needs charging the flash performance deteriorates.

Camera Options

The following functions are available, depending on the current situation.

Options Open menu.

Memory assist. Starts if there is insufficient memory.

Pictures Display list of photos.

Other videos Display list of videos.

Microphone on Switch microphone on or off.

Use flash Automatic, On, Off, Red eye reduct.

Settings

- Name for recordings
- Video resolution
- Image resolution
- Brightness
- Colour mode
- Night mode
- ISO sensitivity
- Flash strength
- Set autotimer
- Location.

Frame Select decorative frame.

Self-timer The photo is taken after a preset time.

White balance Automatic, Indoor, Outdoor

(For standard functions see page 13)

SMS/MMS

You can use your phone to send and receive messages via SMS and MMS (**M**ultimedia **M**essaging **S**ervice).

Information about SMS

You can use your phone to transmit and receive very long messages (up to 760 characters). They are automatically composed of several "normal" SMS messages (note higher charges). Additionally, you can insert pictures and sounds in an SMS.

Information about MMS

The **M**ultimedia **M**essaging **S**ervice enables you to send texts, pictures/videos and sounds in a combined message to another mobile phone or to an e-mail address. All elements of an MMS message are merged to form a "slide show".

Depending on your phone's settings, you will receive either the complete message automatically or notification that an MMS has been saved in the network, giving sender and size details. You may then download it to your phone to read it.

Ask your service provider whether this service is available, and register for it if necessary.

Writing an SMS



→ Create new → SMS



Enter text. You will find information on writing texts with and without T9 in the chapter "Text input", (page 16).

Options

Open menu, then select **Add recipient**.



Enter phone number and ...



... save

or

Select recipient from **Contacts**.



Start sending process.

Writing an MMS



→ → Create new → MMS

An MMS message can consist of a series of pages which may hold text, pictures/videos and sounds (note DRM, page 11). You will find the operating functions in the options menu.

Options Open menu, then select **Add recipient**.



Enter phone number and ...



... save

or Select recipient from Contacts.

If necessary insert a subject:

Open menu, then select **Add subject** and enter a brief description of the MMS.



Start sending process.

Options for writing and sending an SMS/MMS

Options Open.

Save as templ. Save MMS as a template.

Add recipient Add recipient.

Delete recip. Delete recipient.

Add subject Add subject field.

Add item Add contents, such as Text, Pictures/Videos, Sound, Contacts, Attachment

Create item Create contents. Camera/video (page 24), sound recorder (page 49).

Preview Play entire MMS in the display.

Save as draft Store the MMS as a draft.

Text edit menu Input language, Mark text, Copy, Insert

Send options See page 30.

Insert text Text modules, Emoticons (page 30), Signature, Opening sentence, Contact details, Bookmark

Page duration: Enter the lifespan of a page in seconds.

View pictures/Play Play back animations and melodies with the media player.

Open attachm. Play back attachment with the media player.

(For standard functions see page 13)

Receiving

A new incoming message is shown in the display.



Confirm receipt.



Use the softkey underneath to open the **Inbox**.

In order to receive a complete MMS **later on**, the notification must be opened.

Options Open, then select **View**.

Additional options are **Reply/Reply to all**, **Forward**.

Reading



Inbox

Select the **SMS/MMS** tab.



Select the required message.



Read the **SMS/MMS** or the notification about an MMS.

Additional information about MMS:



Scroll up/down within a page.



Jump to next page and return at end to first page.



Jump to the start of a page or to the previous page.

Read options

Different functions are offered depending on the situation.



Open menu.

Save picture Opens the picture folder in **My stuff**.

Play Play back MMS.

Pause Pause playback of an MMS.

Save sound Opens **My stuff** for selection of a folder.

Open link Starts the WAP browser (page 34).

Open item The contents of the MMS are listed for playback with the media player or for saving.

Save item The contents of the MMS are listed for saving in the relevant folder.

Open attachment Play back attachment with the media player.

Save attach. Opens the relevant folder in **My stuff** for saving.

(For standard functions see page 13)

Draft

 →  → Draft → SMS/MMS

The drafts tab is displayed.

Outbox

 →  → Outbox → SMS/MMS

The tab for the messages not sent yet is displayed.

Sent

 →  → Sent → SMS/MMS

The tab for the messages sent is displayed.

Archive

 →  → Msg. archive
→ SMS/MMS

Messages are saved in the archive according to their type and origin. Select tab and read required message(s).

Templates

 →  → Templates
→ MMS templates/Text modules

MMS templates

MMS templates are messages saved without an address. They can be sent as a whole or as part of a new MMS.

Text modules

See page 17.

SMS settings

 →  → Message setup → SMS
→ Select function.

The basic settings have normally already been made by the service provider.

Send options

Set send options such as **Service centre**, **Recipient**, etc.

Creation

Set layout options such as **Add signature**, **Signature**, etc.

MMS settings

 →  → Message setup → MMS
→ Select function.

The basic settings have normally already been made by the service provider.

Send options

Set send options such as **Delivery report**, **Validity period**, etc.

Creation

Set layout options such as **Creation mode**, **Opening sentence**, etc.

Retrieval

Settings for receipt of the message, such as **Retriev.(roam.)**, **Allow deliv.rep.**, **Allow read rep.**, etc.

Connect. sett.

Select the required MMS profile in which the connection attributes are specified. You can obtain the data you need for this from the service provider or at:

www.siemens.com/mobilephonescustomercare

Save after send

 →  → Message setup
→ Save after send

SMS messages are always saved in the **Sent** list after sending.

Text zoom

 →  → Message setup
→ Text zoom

You can select one of three specified text sizes for presenting a message.

Emoticons

 →  → Message setup
→ Emoticons

Emoticons are small symbols (smileys) with which you can show your feelings in pictorial form.

Inst. message



 →  → Inst. message

This function is not supported by all service providers. Please contact your service provider for more information. You will find a description in the comprehensive user guide on the Internet at:


www.siemens.com/s75

E-mail



Your phone has an e-mail program (client).

Writing/sending

 →  → Create new → E-mail

 Enter text.

Options Open menu, then select Add recipient.


 Enter e-mail address(es) and save .

or Select recipient from Contacts.

Additional fields such as **Subject**:, **Cc**:, **Bcc**: are called up via the options menu.

Attachments:

Add attachments such as pictures and sounds.


 Send e-mail.

Receiving/reading

 →  → Inbox → E-mail

Select the E-mail tab.

Before an e-mail can be read, it must be retrieved from the server.

 Open menu, then select Retrieve e-mail/Retrieve body.

 Select message.

 Read message.

Additional options include Reply, Forward, Save attach..

Draft/Sent/Archive

 → 
→ Draft/Sent/Msg. archive
→ E-mail

The tab for the messages not sent yet/sent/archived is displayed.


Setting

 →  → Message setup
→ E-mail setup → Accounts

Before using this service you must set the server access and your e-mail parameters. You will receive the necessary data from the service provider or at:

www.siemens.com/mobilephonescustomer-care

 Select account.

 Activate an existing account **or**

Options Open, and select Edit. Complete settings as indicated by the service provider (page 39).

WAP push

WAP push messages are transmitted from special service centres. If, for example, you have requested configuration data from your service provider this will be transmitted via WAP push.

Inbox



Open the tab **WAP push** in the inbox.



Select the required message.



Read the message or information about the transmitted data/programs and, if applicable, trigger a download.

Inbox Options

Different functions are offered depending on the situation.

Options Open menu.

Execute	Execute program.
Install	Start installation.
Accept/Reject	Accept/reject message.
Settings	Call up settings.

Message setup



Options Open menu, then select **Settings**.

Allow push	Settings to receive WAP push messages: Allow specific, Allow none, Allow all If Allow specific has been set, the following lists may be edited.
Accept list	All messages whose senders are included in this list are accepted (max. 20 entries possible).
Reject list	All messages whose sender is included in this list are automatically deleted (max. 20 entries possible).
Unknown addr.	Handling of messages whose senders are neither in the accept nor the reject list: Reject, Delete

Voice mailbox/CB services

Voice mailbox



→  → Voice mailbox

Most service providers provide a mailbox in which a caller can leave voice mail for you. If the voice mail service is not part of your service provider's standard package, you will need to register for it, and possibly set it manually.

Setup



The service provider supplies you with two phone numbers:

Save mailbox number

Call this phone number to listen to your voice messages.



→  → Voice mailbox

Enter/edit the phone number and confirm with **OK**.

Save call divert number

Calls are diverted to this phone number.



→  → Call setup
→ Divert

Options

Open, then select e.g. **Unanswered** and then **Set**.



Enter phone number.

Options


Open, then select **Save**.

Listening



A new voice message can be announced as follows, depending on the service provider:



 Symbol with beep/an SMS or a call with automatic announcement.

Call your mailbox and play the message(s) back.



Hold **down** (if necessary enter mailbox number once only). Confirm with **OK** and **Mailbox** depending on your service provider.

CB services



→  → CB services

Some service providers offer information services (info channels, **Cell Broadcast**). If reception is activated, you will receive messages on the activated topics in your **Topic list**.

Internet



→ → Internet
→ Select function.

Download games, applications, sounds, graphics and more for your phone at **wap.siemens.com** ("Downloads"). Internet access may require registration with the service provider.

Access to the service provider

Direct call-up of the browser with the URL from your service provider.

Downl. assist.

You will not be left on your own during the download.

Enter URL

On input the browser is started and the page displayed.

Bookmarks

List bookmarks

Display list and select a bookmark.



Call up URL.

Saving

Bookmark site

The current page is saved as a bookmark.

Internet

The browser is started with the pre-set option.

Browser menu

Options Open menu.

Homepage	Call up the pre-set homepage of the current profile.
Bookmarks	Display stored list of bookmarks; save bookmark.
Go to...	Enter a URL
Reload	Reload current page.
Show URL	Display the URL of the current page for sending via SMS/MMS/e-mail.
History	Display most recently visited Internet sites.
Disconnect	Disconnect the Internet.
File	Save the object on the current page or the complete page; display saved pages.
Setup	Set or reset browser.
Exit browser	Close the browser.

End connection



Press to clear down the connection and close the browser.

Navigation in the browser



- Select a link.
- Settings, status on/off.




- Press **briefly**: go back a level.




- One input field/link forward/back.
- Scroll one line.

Display symbols in the browser (selection)



Enter special characters



Select important special characters.

Browser settings



→ Internet

Options Open menu.

Setup Select.

Browser Set start option as well as handling of pictures/sounds plus send options.

Profiles The list of profiles is displayed for activation/setting.

Protocol parameters Set protocol parameters, push messages and abort time as well as handling of cookies.

Security Set encryption.

Context Reset session; delete cache, history and cookies.

Profiles

Processing depends on the service provider (see page 39).

Your Internet browser is Licenced by:



OPENWAVE™



History

Display most recently visited Internet sites.

Saved websites

Display list of pages stored in the phone.

Setup

Profiles



Several settings can be stored in a phone profile in order, for example, to adapt the phone to the surrounding level of noise.

- Six profiles are provided with default settings. They can be changed however:
General, Vibration, Meeting, Outdoor, Car Kit, Headset
- You can name two personal profiles (<Name>).



Select default profile or personal profile.



Activate the profile.

Changing profile settings

Edit a default profile or create a new personal profile:



Select profile.

Options Open menu.

Change sett.
Select.

When you have finished setting a function, you return to the profile menu where you can change a further setting.



Car Kit

If an original Siemens Car Kit is used, the profile is activated automatically when the phone is inserted into the cradle.

Headset

If an original Siemens headset is used, the profile is activated automatically when the headset is in operation.

Additional information

- To call up the list in standby mode:
 profile list is displayed.
- The active profile is identified with .

Ringtones



Set the volume for all tones. You can make individual settings for different functions.

Themes



Load a completely new visual presentation onto your phone. Various functions are re-organised on a theme basis at the press of a key, e.g.

Animations, Sounds, Colour skins, Font, Wallpaper

Theme files are compressed to save memory space. After a download or a call from **My stuff**, these are automatically unzipped when activated.



Select theme.



Activate; if required, view **Preview**.

Display



Wallpaper

Set wallpaper graphic for the display.

Logo

Choose picture to be displayed instead of the provider logo.

Screensaver

After a specifiable time, the screen-saver shows a picture in the display. An incoming call and/or pressing any key will end the function except if the code security with the telephone code is activated.

Start up anim./Shutdown anim.

Shown when the phone is switched on/off.

Own greeting

Displayed instead of an animation when you switch on the phone.

Big letters

You can choose between two font sizes for the display.

Illumination

Set display light brighter/darker.

Vibration



To avoid the disturbance caused by a ringing phone, you can activate the silent alert function as an alternative for various applications. The silent alert can be switched on in addition to the ringtone (e.g. in a noisy environment).

Phone Pilot



Phone Pilot

Your Phone Pilot will provide you with information for many actions that you carry out with your phone. It will also remind you about appointments or birthdays and will show you important phone functions. A Phone Pilot is available on the phone as standard and cannot be deleted.

Connectivity



Connectivity

IrDA

Your phone has an infrared interface. The distance between the two devices must not exceed 30 cm. The infrared windows in the appliances must be aligned as accurately as possible with each other.

EGPRS

EGPRS is a method for transmitting data in the mobile network faster than with GPRS.

EGPRS info

Display information on connection status.

Bluetooth® (BT)

Activate/deactivate Bluetooth, give your phone a Bluetooth name, and manage the list of known Bluetooth devices. If Bluetooth is activated, IrDA (infrared) is not active and vice versa.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Siemens is under licence. Other trademarks and trade names are those of their respective owners.
Bluetooth QDID (Qualified Design ID): B02422

Bluetooth setup



Bluetooth activation.

My BT name: Give the phone a name the first time it is switched on.

Search

Specify which BT devices are to be searched for.

Device list

- **Known devices**

Record frequent BT partners in the list of known devices. If entries are "confidential", no password query is made.

- **Last connected**

List of most recently and/or still connected devices.

- **Reject list**

Attempts to make connections to devices in this list are rejected.

- **Last srch.result**

List of the last devices found.

My BT name

The phone is given a name (max. 20 characters) – this is the name the partner sees. If no name is given, the phone uses the non-changeable device address.

Visib.to others

Make settings to specify how your phone should "act" when in contact with other BT devices. This means (if "visible"), for example, that the device address or the BT name of your phone is shown to other BT devices if they request this in order to receive or send data.

- **Not visible**

Your phone is not "visible" to other BT devices. Known devices such as the Bluetooth Headset/Car Kit continue operating.

- **Auto mode**

Your phone is "visible" to other BT devices for five minutes. You will then be asked if "visibility" should continue.

- **Always visible**

Your phone is always "visible" to other BT devices. These devices can create a connection to your phone and be added to the known device list if necessary.

BT audiostream

When a Bluetooth headset is used, all audio signals are transmitted to this exclusively.

Shown in the display



Bluetooth activated.



Bluetooth visible to others.

Configura. set

Default setting and activation of the connection profiles for data transmission. The phone default setting varies from service provider to service provider. Consult your service provider or go to this address on the Internet for more information
www.siemens.com/mobilephonescustomer-care

Fax/data

Send voice/fax

Set this function on the phone **before** transmission so that you can switch from voice mode to fax mode.

Rec. fax/data

The call is signalled by a special ringtone and the type of call (fax or data) is displayed. Now start the communication program in your PC to receive the fax/data.

Shortcuts



Soft keys

You can assign one function to each of the two softkeys.



Select key.



Call up the edit function.



Scroll to new assignment in the list.



Confirm.

Apply

The "Internet" is just used as an example here.

Internet Press. The application is started.

Additional information

The service provider may have already assigned functions to all the keys (e.g. access to "SIM services" or direct call-up of the Internet portal). It may not be possible to modify this key assignment.

Navigation keys

The navigation key can be assigned a function for three directions (only effective in standby mode). The downwards movement is assigned to opening contacts and cannot be modified.

Number keys

Number keys 2 to 9 can be used as speed dialling numbers for fast access to functions. **Number key 1** is reserved for the mailbox phone number.

Assigning numbers or functions



Select the key.



Call up the edit function.



Choose application from the list.



Confirm selection.

Key tones

Set the type of acoustic key acknowledgement.

Click, Tone, Silent

Show functions

Show the functions set for the number keys.

Call setup



Hide ID



If activated, your phone number will not appear on the other party's display (depending on the service providers).

Call waiting



If you are registered for this service, you can check whether it is set and you can activate/deactivate it.

Divert

You can specify when calls should be diverted to your mailbox or other phone numbers.

Setting up call divert (example)

Unanswered



Select **Unanswered**. (Includes the conditions **Not reachable**, **No reply**, **Busy**, see below.)



Confirm and select **Set**, then enter the phone number to which the call is to be diverted.



Confirm. The setting is confirmed by the network.

All calls



All calls are diverted.



Symbol in the top line of display in standby mode.

Other possibilities for divert:

Not reachable, **No reply**, **Busy**, **Receiving fax**, **Receiving data**

Call screening

Only calls from phone numbers that are in the Phonebook/Addressbook or in a group are signalled audibly. Other calls are only displayed.

Any key answer

Incoming calls can be accepted by pressing any key (except for).

Minute beep

During the call, you (and only you) will hear a beep after each minute as a reminder of the time elapsed.

Phone setup



Language

Set the language for the display text, the input language for text input, and import/export databases for T9.

Key tones

Set the type of acoustic key acknowledgement.

Info tones

Set service and alarm tones.

Automatic switch off

The phone switches off each day at the set time.

File system

Format

(Phone-code protected)

The telephone memory is formatted and **all** saved data such as ringtones, pictures, games, etc. is deleted.

Format card

All data saved on the RS MultiMedia-Card is deleted.

Eject card

Remove the RS MultiMediaCard without loss of data.

Licence manag.

The Licenced data/applications can be displayed and managed (see also DRM, page 11).

Phone identity

The phone identity number (IMEI) is displayed. This information may be useful for customer service.

Device check

After the last information page, a self-test (all individual tests) as well as individual tests are offered.

Software version

* # 0 6 #, then press .

Memory assist.

The memory assistant will help you if there is insufficient phone memory.


Device manag.

The device manager can be used, for example, to transfer configuration data from the service provider via WAP push (page 32).

Master reset

The phone is reset to the default values (factory setting). This does not affect SIM card and network settings.

In standby mode enter:

* # 9 9 9 9 # 

Clock



Time/date

The clock must be set to the right time once at start-up.



Start editing and enter date/time.

Time zones

Choice of time zone:

World map



Select the desired time zone.

City list



Select a city in the selected time zone.

Time format

Select 24h or 12h.

Date format

Select the display format for the date.

Begin of week

Weekday on which the monthly and weekly view on the left starts.

Buddhist year



Change over to Buddhist year.

Show clock

Activate/deactivate the time display.

Auto time



Time and time zone are set automatically. The time zone is detected automatically.

Security



Auto key lock

The keypad is locked automatically if no key has been pressed for a specific time. However, you can still be called and you can still make an emergency call.

Lock/unlock keypad in standby mode. In each case:



Press and **hold**.

Direct call

Only **one** phone number can be dialled.

Only



Restrict calls to SIM-protected numbers in the Phonebook.

This SIM only



Your phone is prevented from being used with a **different** SIM card.

Certificates

Display certificates for secure data connections.

PIN codes

For description, see page 14:

PIN control, Change PIN, Change PIN2, Chg. phonecode

Barrings



Network barring restricts the use of your SIM card.

All outgoing

All outgoing calls except emergency numbers are barred.

Outgoing intl. (outgoing international)

Only national calls can be made.

Out.int.x.home (international outgoing without home country)

No international calls, only calls to the home country.

All incoming

The phone is barred for all incoming calls.

When roaming

You will not receive calls when outside your home network.

Status check

Status check for network barring.

Clear all

Clear all network barrings.

Network



Line



There must be **two independent** phone numbers registered.

Network info

The list of GSM networks currently available is displayed.

Choose network

Network search is restarted.

Preferred netw.

If activated, the next network is dialled in the order of your "preferred networks".

Band selection



Select either GSM 900, GSM 1800, or GSM 1900.

Fast search

Network reconnection is speeded up.

User group



Depending on your service provider, you can create groups with this service. These have access, for example, to internal (company) information, or special tariffs apply to them. The details can be clarified with your service provider.

Accessories



Car Kit

Only in combination with an original Siemens handsfree car kit (see accessories). The car kit profile is activated automatically when the phone is inserted into the cradle.

Edit profile

See page 36.

Auto answer

(Factory default: off)

Calls are accepted automatically after a few seconds. Eavesdropping is possible!

Or

Answer by removing from the cradle (not while driving).

Auto answer

If you do not notice that your phone has accepted a call, there is the danger that the caller may eavesdrop.

Automatic switch off

(Factory default: 2 hours)

The phone is powered by the car's power supply. You can adjust the time between switching off the ignition and the time at which the phone switches off automatically.

CarKit speaker

Improves playback in certain circumstances.

Car Kit keys

Key assignment when working together with Car Kit Comfort.

Headset

Only in conjunction with an original Siemens headset (see accessories). If an original Siemens headset is used the profile is automatically activated when the headset is plugged in.

Edit profile

See page 36.

Auto answer

(Factory default: off)

Calls are accepted automatically after a few seconds (except where the ringer is switched off or set to beep). You should therefore be wearing the headset.



Automatic setting

Accept call with Call key or Call acceptance key, even when the auto key lock is activated.

USB charging

If the phone is connected with the data cable to a PC, the battery can also be charged in this way (only with original Siemens accessories).

Organiser

 →  → Select function.

Calendar

You can enter appointments in the calendar. Time and date must be set for the calendar to work correctly. The calendar offers you three views: monthly view, weekly view, and daily view. Appointments are shown as a colour bar on the vertical hour division. Conflicting appointments are highlighted in colour.

 /  Scroll between weeks/days/hours.


Appointments


Appointments are displayed in chronological order in a list.


Enter new appointment

<New entry>
Select.

Category:

 **Memo:** Text input for description.

 **Voice reminder:** Enter voice memo. Shown with alarm.

 **Call:** Enter phone number to be displayed with the alarm.



Meeting: Text input for description.



Holiday: Enter start and end date.



Birthday: Enter name and date.

Different input/selection fields are displayed depending on the type. The number of fields can be restricted, see **All fields/Reduced fields** at the end of the list.

Additional information

An alarm sounds even when the phone is switched off. To deactivate it press any key.

Tasks

A task is displayed like an appointment in the agenda for the selected day. However, unlike an appointment it does not require a time. When no time is entered the task appears at the top of the list every day until it is marked as completed. The first entries are similar to those for **Appointments**.

Notes

 →  → Notes

Write and manage text notes. Protect confidential information using a phone code.

Dictat.machine



Use the dictating machine to record short voice memos or for recording calls.

New recording

Record new

Select.



A brief beep sounds when the recording starts. Now dictate the text.



Switch between pause/record.

Stop

End recording. Recording is saved with a time stamp. Rename with **Options**.

Playback (via Media player)



Select the desired recording.



Switch between playback/pause.



Press and hold, for fast forward and rewind.

Warning!

The use of this feature may be subject to restrictions under criminal law. Please inform the other party to the conversation in advance if you want to record the conversation and please keep such recordings confidential. You may only use this feature if the other party to the conversation agrees.

Time zones

(see page 43)

Remote synchronisation

You can use this function remotely to synchronise the personal data on your phone (contacts, notes, calendar entries) with externally saved data.

Synchronisation

Before synchronisation you must select a profile (**Active account**) and a data area and enter the correct path to the data (**Server sett.**). Confidential notes are not transferred.

Sync

The computer is selected and synchronisation started.

Two profiles can be set for synchronisation.

Extras



→ Select function.

SIM services (optional)

Your service provider may offer special applications such as mobile banking, share prices, etc. via the SIM card.



Symbol for SIM services.

For further information, please contact your service provider.

My applications

To help you organise the applications you download from the Internet you can use the **My applications** folder in **My stuff**.

For further information, see page 53.

Calculator

The calculator is offered in a basic version and with an advanced range of functions.

The input line is in the middle of the display with two calculation lines above it. Beneath it is the matrix with the calculation functions.



Enter digit(s).



Navigate to functions in the matrix.



Accept function.



Enter digit(s).



Apply function. The result is calculated and displayed immediately.

Unit converter

You can convert various measurement units in the decimal system into other measurement units.



Select the source unit/currency.



Switch to the input field, enter amount, and then switch to the selection field.



Select the target measurement unit/currency. The result is displayed.

You can use both input fields alternately.

Special key functions:



Set the decimal point.



Change the preceding sign.

Currency

When you call up the function for the first time, you must enter currencies into which the conversions are to be made.



Enter the name of the currency (e.g. Euro).

Options

Open menu and select with **Save**.

Now enter the names and exchange rates of up to three additional currencies for conversion.

Online status

The application can be called up from various other applications, such as **Inst. message** or from **Contacts**. In **Online status** you can set such attributes as "Availability" or "Mood", which are visible to subscribers to **Inst. message**. You can also edit your status lists for the respective service here.

Sound recorder

Use the sound recorder to record noises and tones for use as ringtones. The sound recorder is usually started from other applications/functions such as assigning a ringtone.

New recording

New entry Select.



A brief beep sounds when the recording starts.



Switch between pause/record.

Stop

The recording is ended and saved with a time stamp. **Rename** with **Options**.

Playback (via Media player)



Select the desired recording.



Switch between playback/pause.



Press and **hold** for fast forward and rewind.

Stopwatch

The stopwatch can work with lap times and intermediate times.

With **Lap timing**, each time a time is taken the stopwatch returns to zero.

With **Split timing**, the clock continues to run and the respective intermediate time is stored (max. 99).



Start, stop or continue, depending on the situation.

Lap / Split Store the current intermediate/lap time.

Countdown

A set time elapses. It is possible to call up or set five timings with different countdown times.

Date calculator

Calculate the period between two specified dates.

My menu

Create your own menu with frequently used functions, phone numbers or Internet pages.

Alarm clock



The alarm sounds at the set time even when the ringtones or the phone are switched off. The alarm clock is activated automatically after a change is made.

An alarm is ended by pressing any number key.



Set the time for the alarm call (hh:mm).

Or



Activate/deactivate the alarm clock.

Setting the days for an alarm

Options Open the menu and select **Set days**.



Switch between the days of the week.



Mark or unmark the days for an alarm.

Save

Save the alarm call time.

Alarm clock Options

Options Open menu.

Change	Set the alarm call time. Switch between am and pm if 12 hour mode set.
Set days	Set the days for an alarm.
Ringtones	Set ringtone.
Clock	Set time (page 43).
Setup	Activate/deactivate: <ul style="list-style-type: none"> • Auto snooze • Vibration

(For standard functions see page 13)

Additional information



Screen display in standby mode:
alarm clock activated.

Use **Snooze** to set the current alarm to repeat.

Media player

Starting from an application

When you are viewing a picture/ video or listening to a melody, the application starts a media playback.

Direct number for the media player



Press key

or



All the media files on your phone are offered on four tabs:

Sounds, Playlist, Pictures, Videos



Select tab.



Select file and start playback.

Sounds/Videos

Play back melodies or videos.



Play or pause, depending on the situation.



Fast forward/rewind while key is pressed.



Load next/previous media file.



Set volume.



Switch to mute.



Switch to full screen mode and back again.



End playback.

Playlist

Several pieces of music are compiled in a playlist (*.m3u).



Open menu, select **New** and then **Playlist**.

Pictures



Zoom function. Zoom in/out with the (+/-) softkeys.



Move enlarged picture detail.



Centre picture.

Centre key functions:



Play, play back



Pause



Stop

Incoming call

An incoming call pauses the playback and puts the media player into the background. After the call has ended the playback continues automatically.

Playback in the background



Press key repeatedly to switch: foreground or background operation.

My stuff

To organise your files, you can use the file system like a PC file manager. There are separate folders for the various data types in **My stuff**.



The list of the folders and files is displayed (on two tabs if an RS MultiMediaCard is used).



Select file or folder.



Open folder and select file or link. Depending on the selection, the file with the associated application is opened or the download started.

Download

Melodies, pictures, games and other applications are offered on the Internet. Once downloaded, you can access these via the phone. Most applications include instructions. The appropriate folders contain the download function to download e.g. new pictures and sounds.

Remember that pictures and sounds may be protected (DRM, page 11).

Some applications and games are already pre-installed on your phone.

Downloading can, if necessary, take place in two stages:

Description file only



The description file is loaded for information purposes only. The application/game itself must be loaded separately.

or complete download



The application/game is completely loaded.

Additional information

You can use the browser to download applications (e.g. ringtones, games, pictures, animations) from the Internet.

Siemens excludes all warranty and liability claims in respect of or in connection with any applications subsequently installed by the customer and any software not included in the original delivery package. This also applies to functions enabled subsequently at the customer's instigation. The buyer bears the sole risk for loss, damage or faults to the phone or application as well as all damage and implications arising from the application. For technical reasons, such applications or the retrospective release for certain functions may be lost if the phone is exchanged/re-delivered or repaired. In such cases, the buyer is required to download or release the application again. Please ensure that your phone has Digital Rights Management (DRM) so that downloaded applications are protected from unauthorised reproduction.

These applications are then exclusively intended for your phone and cannot be transferred from this even to create a backup. Siemens does not warrant, guarantee or accept any liability for the customer's ability to download or enable applications again or to do so free of charge. We recommend that you carry out a backup from time to time of the applications on your PC using the "Mobile Phone Manager". You will find this on the supplied CD-ROM. You can download the relevant latest version of the MPM from the Internet at:

www.siemens.com/s75

Directory structure

Separate folders have already been created for different data types in **My stuff**. These folders cannot be changed.

Folder	Description	Format
	The structure and contents can vary, depending on the service provider	
Sounds	Sounds, ringtones	mp3 aac aac+ aac++ m3u mid amr wav
Pictures	Pictures	bmp bmx jpg jpeg png gif
Videos	Videos	3gp
Themes	Loaded theme (zipped)	sdt
	Theme configuration (unzipped)	stc
Phone Pilot	Selection of a character	sda
Games	Java archive	jar
	Download info	jad

Applica- tions	Applications, such as Photo Editor or Download Assistant	*
Misc.	Text modules	tmo
	Voice recordings	vmo
	Internet pages	html wml

Arranging files

After the media player starts the following tabs are displayed:

Songs

All AAC, AAC+, AAC++ and MP3 files are displayed.

Playlists

All playlists (file format: .m3u) are displayed.

Pictures/Videos

All supported picture and video formats are displayed.

All files stored in the phone or on the RS MultiMediaCard are automatically shown in a list in the tabs. This list can be arranged according to the meta data (ID3 Tags) according to album, artist, genre or title.

RS MultiMediaCard™

The RS MultiMediaCard extends the memory capacity of your phone by up to a gigabyte. This permits you, for example, to store a large number of pictures, videos or sounds. You can also use the memory card as a removable medium (see page 8).



Open
RS MultiMediaCard tab

The list of the folders and files is displayed. The folders and files are treated as in **My stuff**. If a file is opened whose application is in the phone the file is copied to there.

RS MultiMediaCard™ is a trademark of the MultiMediaCard Association.

Mobile Phone Manager

MPM (Mobile Phone Manager) enables you to use extended phone functions from your PC. The phone and PC communicate via a data cable (see Accessories), IrDA or Bluetooth. MPM offers you a large number of functions.

You can manage your address data and contacts and synchronise them with other phones (including Gigaset), dial at the press of a button, and manage phone conferences. Creating, reading, saving and sending SMS messages is also supported.

MPM makes managing your music and sound files, playlists, ringtones and videos effortless. At the click of a mouse you can transfer the entire contents of a music CD to your phone in the form of space-saving AAC or MP3 files, maintaining first class quality.

With MPM you can easily and conveniently edit your photos, pictures and wallpaper logos and add a wide variety of effects.

Mobile Modem Assistant enables you to use your phone conveniently and easily as a modem both at home and when travelling. You can easily compile your WAP favourites and copy them to your phone.

Naturally the data and settings on your phone can also be backed up on your PC with MPM. With Phone Ex-

plorer you can access the files in your phone as if it was simply another folder in your PC.

If wished, the software also automatically takes over such routine tasks as synchronising your contacts, downloading the latest photos you have taken, or updating your music files.

MPM, a detailed user guide, and on-line help are contained on the CD enclosed with this phone. You can download future versions of the software from the Internet at:

www.siemens.com/s75


Customer Care

We offer fast, individual advice! You have several options:

Our online support on the Internet:

**[www.siemens.com/
mobilephonescustomer-care](http://www.siemens.com/mobilephonescustomer-care)**

We can be reached any time, any place. You are given 24 hour support on all aspects of our products. Here you will find an interactive fault-finding system, a compilation of the most frequently asked questions and answers, plus user guides and current software updates to download.

When calling customer service, please have ready your receipt and the phone identity number (IMEI, to display press *#06#), the software version (to display, press *#06#, then ) and if available, your Siemens Service customer number.

Qualified Siemens employees are waiting to offer you expert information about our products and installation.

In some countries repair and replace services are impossible where the products are not sold through our authorised dealers.

If repair work is necessary, please contact one of our service centres:

Abu Dhabi	0 26 42 38 00
Argentina	0 80 08 88 98 78
Australia	13 00 66 53 66
Austria	05 17 07 50 04
Bahrain	40 42 34
Bangladesh	0 17 52 74 47
Belgium	0 78 15 22 21
Bolivia	0 21 21 41 14
Bosnia Herzegovina	0 33 27 66 49
Brunei	02 43 08 01
Bulgaria	02 73 94 88
Cambodia	12 80 05 00

Canada	1 88 87 77 02 11
Chile	8 00 53 06 62
China	0 21 23 01 71 88
Colombia	01 80 07 00 66 24
Croatia	0 16 10 53 81
Czech Republic	2 33 03 27 27
Denmark	35 25 86 00
Dubai	0 43 96 64 33
Ecuador	18 00 10 10 00
Egypt	0 23 33 41 11
Estonia	6 30 47 97
Finland	09 22 94 37 00
France	01 56 38 42 00
Germany	0 18 05 33 32 26
Greece	80 11 11 11 16
Hong Kong	28 61 11 18
Hungary	06 14 71 24 44
Iceland	5 11 30 00
India	22 24 98 70 00 Extn: 70 40
Indonesia	0 21 46 82 60 81
Ireland	18 50 77 72 77
Italy	02 24 36 44 00
Ivory Coast	05 02 02 59
Jordan	0 64 39 86 42
Kenya	2 72 37 17
Kuwait	2 45 41 78
Latvia	7 50 11 18
Lebanon	01 44 30 43
Libya	02 13 50 28 82
Lithuania	8 70 07 07 00
Luxembourg	43 84 33 99
Macedonia	02 13 14 84
Malaysia	+ 6 03 77 12 43 04
Malta	+ 35 32 14 94 06 32
Mauritius	2 11 62 13
Mexico	01 80 07 11 00 03
Morocco	22 66 92 09
Netherlands	0 90 03 33 31 00
New Zealand	08 00 27 43 63
Nigeria	0 14 50 05 00
Norway	22 70 84 00
Oman	79 10 12
Pakistan	02 15 66 22 00
Paraguay	8 00 10 20 04

Peru	0 80 05 24 00
Philippines	0 27 57 11 18
Poland.....	08 01 30 00 30
Portugal	8 08 20 15 21
Qatar	04 32 20 10
Romania	02 12 09 99 66
Russia.....	8 80 02 00 10 10
Saudi Arabia	0 22 26 00 43
Serbia	01 13 07 00 80
Singapore	62 27 11 18
Slovak Republic	02 59 68 22 66
Slovenia.....	0 14 74 63 36
South Africa	08 60 10 11 57
Spain.....	9 02 11 50 61
Sweden.....	0 87 50 99 11
Switzerland	08 48 21 20 00
Taiwan	02 23 96 10 06
Thailand.....	0 27 22 11 18
Tunisia	71 86 19 02
Turkey.....	0 21 64 59 98 98
Ukraine	8 80 05 01 00 00
United Arab Emirates.....	0 43 66 03 86
United Kingdom	0 87 05 33 44 11
USA	1 88 87 77 02 11
Venezuela.....	0 80 01 00 56 66
Vietnam.....	84 89 20 24 64
Zimbabwe	04 36 94 24

Care and maintenance

Your phone has been designed and manufactured to the highest of standards and should be treated with great care. The suggestions below will help you to enjoy your phone for many years.

- Protect your phone from moisture and humidity. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits. Nevertheless, should your phone become wet, disconnect it immediately from the power supply to avoid electric shock. Do not place your phone (even to dry it) on/in a source of heat such as a microwave oven, oven or radiator. The phone may become overheated and possibly explode.
- Do not use or store the phone in dusty, dirty areas. Its moving parts may be damaged and the casing may become deformed and discoloured.
- Do not store your phone in hot environments (e.g. vehicle instrument panel in the summer). High temperatures can shorten the life of electronic devices, damage batteries and warp or melt certain plastics.
- Do not store your phone in cold environments. When the phone warms up again (to its normal ambient temperature), moisture can form inside the phone, which may damage electronic circuit boards.
- Do not drop, knock or shake your phone. Rough handling can damage internal circuit boards!
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone!

The suggestions given above apply equally to your phone, battery, charger and all accessories. If any of these parts is not working properly, obtain fast and reliable help at our service centres.

Battery quality statement

The capacity of your mobile phone battery will reduce each time it is charged/emptied. Storage at too high or low temperatures will also result in a gradual capacity loss. As a result the operating time of your mobile phone may be considerably reduced, even after a full recharge of the battery.

Regardless of this, the battery has been designed and manufactured so that it can be recharged and used for six months after the purchase of your mobile phone. After six months, if the battery is clearly suffering from loss of performance, we recommend that you replace it. Please buy only Siemens original batteries.

Display quality declaration

For technological reasons, a few small dots with different colours may appear in the display in exceptional cases.

Just remember that the appearance of brighter or darker dots generally does not mean that a fault has occurred.

Product data

Declaration of conformity

BenQ Mobile hereby declares that the phone described in this user guide is in compliance with the essential requirements and other relevant provisions of European Directive 1999/5/EC (R&TTE). The relevant declaration of conformity (DoC) has been signed. Please call the company hotline if you require a copy of the original:

www.siemens.com/mobiledocs

Uygunluk bildirimi

BenQ Mobile, bu kullanım kılavuzunda sözü edilen mobil telefonun 1999/5/EC (R&TTE) tarih ve başlıklı yönergede yer alan hükümlerine ve temel taleplerine uygun olduğunu beyan eder.

İlgili uygunluk bildirimi (DoC) imzalanmıştır. Gerekirse aslının bir kopyasını, şirket yardım hattı üzerinden talep edebilirsiniz veya İnternet'te bkz.:

www.siemens.com/mobiledocs

Manufacturer and Conformity Information

Manufacturer

BenQ Mobile GmbH & Co. OHG
Haidenauplatz 1
D-81667 München
Germany

Telefon: +49 89 722 0
Fax: +49 89 722 913 311

www.siemens.com/mobilephonescustomercare

Importer

Siemens Sanayi ve Ticaret A. Ş.
Yakacak Yolu No: 111
34861 Kartal
İSTANBUL

Telefon: 0216 - 459 2000
www.siemens.com.tr

Notified Body

BABT
Clarmemont House,
34 Molesey Road
Walton-on-Thames
Surrey KT12 4RQ
United Kingdom

Telefon: +44 1932 251 251
Fax: +44 1932 251 252
e-mail: Customer.Services@babt.com

This product has a 7 year lifetime.

CE 0168

Technical data

GSM class:	4 (2 watt)
Frequency range:	880–960 MHz
GSM class:	1 (1 watt)
Frequency range:	1,710–1,880 MHz
GSM class:	1 (1 watt)
Frequency range:	1,850–1,990 MHz
Weight:	99 g
Size:	103 × 47 × 18.5 mm (84 ccm)
Li-Ion battery:	820 mAh
Operating temperature:	–10 °C to 55 °C
SIM card:	1.8 and 3.0 V
RS MultiMediaCard	max. 1 GB

Operating time

Talktime: up to 300 minutes

Standby time: up to 300 hours

The operating time depends upon the respective conditions of use. Extreme temperatures considerably reduce the standby time. You should therefore avoid the leaving the phone in the sun or on a radiator.

The following applications reduce the standby time and can be deactivated if required:

- Flash (page 25)
- CB services (page 33)
- Screensaver (page 37)
- Illumination (page 37)
- Bluetooth (page 38)
- IrDA (page 38)
- Fast search (page 44)
- EGPRS (page 38)

Phone ID

You will need the following information if you lose your phone or SIM card:
the number of the SIM card (on the card):

.....

15-digit serial number of the phone
(under the battery):

.....

the customer service number of the service
provider:

.....

Lost phone

If you lose your phone or SIM card, contact your service provider immediately to prevent misuse.

Limited Manufacturer's Guarantee

Without prejudice to any claim the user (customer) may have in relation to the dealer or retailer, the customer shall be granted a limited manufacturer's Guarantee under the conditions set out below:

- In the case of new devices and their components exhibiting defects resulting from manufacturing and/or material faults within 12 months of purchase, SIEMENS shall, at its own option and free of charge, either replace the device with another device reflecting the current state of the art, or repair the said device.
- This Guarantee shall be invalid if the device defect is attributable to improper treatment and/or failure to comply with information contained in the user manuals.
- This Guarantee shall not apply to or extend to services performed by the authorised dealer or the customer themselves (e.g. installation, configuration, software downloads). User manuals and any software supplied on a separate data medium shall be excluded from the Guarantee.
- The purchase receipt, together with the date of purchase, shall be required as evidence for invoking the Guarantee.
- Ownership of devices or components replaced by and returned to Siemens shall vest in Siemens.
- This Guarantee shall apply to new devices purchased in the European Union and Turkey. For Products sold in Turkey that are imported by SIEMENS Sanayi ve Ticaret A.Ş., a separate importer's warranty is issued by SIEMENS Sanayi ve Ticaret A.Ş. Yakacık Caddesi No: 111 KARTAL ISTANBUL.

- Any other claims resulting out of or in connection with the device shall be excluded from this Guarantee. Nothing in this Guarantee shall attempt to limit or exclude a Customers Statutory Rights, nor the manufacturer's liability for death or personal injury resulting from its negligence.
- The duration of the Guarantee shall be extended by the time period used for services rendered under the terms of the Guarantee.
- Insofar as no Guarantee default exists, Siemens reserves the right to charge the customer for replacement or repair.
- The above provisions do not imply a change in the burden of proof to the detriment of the customer.

To invoke this Guarantee, please contact the Siemens telephone service. The relevant number is to be found in the accompanying user guide.

Sınırlı Üretici Garantisi

Kullanıcının (müşterinin) satıcı veya perakendeci ile ilgili herhangi bir tazminat talebine dokunmaksızın, müşteriye aşağıda belirtilen koşullar altında bir sınırlı Üretici Garantisi verilecektir:

- Yeni cihazların ve parçalarının satın alma tarihinden itibaren 12 ay içinde imalat ve/veya malzeme hatalarından dolayı kusurlu çıkmaları durumunda, SIEMENS kendi seçimine kalmış bir şekilde ve bedelsiz olarak cihazı mevcut teknolojiyi yansıtan başka bir cihazla değiştirecek veya sözkonusu cihazı tamir edecektir.
- Eğer cihazdaki kusur yanlış kullanımdan veya kullanıcı kılavuzlarındaki bilgilere uyulmamasından kaynaklıyorsa bu Garanti geçersiz olacaktır.
- Bu garanti, yetkili satıcı veya müşterinin kendisi tarafından gerçekleştirilen servisler (örn. Kurulum, yapılandırma, yazılım indirme) için uygulanmayacak veya bunları kapsayamayacaktır. Kullanıcı kılavuzları veya ayrı bir veri aracı üzerinde temin edilen yazılımlar Garanti kapsamında yer almayacaktır.
- Garanti talebinde bulunmak için kanıt olarak satın alma tarihini içeren satın alma makbuzuna gerek olacaktır.
- Siemens tarafından değiştirilen ve Siemens'e iade edilen cihazların veya parçaların mülkiyeti Siemens'e ait olacaktır.
- Bu Sınırlı Üretici Garantisi Avrupa Birliği ülkelerinde ve Türkiye'de geçerli olacaktır. Türkiye'de satılan SIEMENS Sanayi ve Ticaret A.Ş. ithalatı ürünler için ayrıca SIEMENS Sanayi ve Ticaret A.Ş. Yakacık Caddesi No: 111 KARTAL ISTANBUL tarafından ithalatçı Garanti belgesi düzenlenmektedir.

- Cihazdan kaynaklanan veya onunla bağlantılı diğer talepler bu Garanti kapsamı dışında olacaktır. Bu Garantide yer alan hiçbir şey, Müşterinin Yasal Haklarını veya imalatçının ihmalden dolayı meydana gelen ölüm veya yaralanma bakımından imalatçının yükümlülüğünü sınırlandırmayacak veya kapsam dışı bırakmayacaktır.
- Garantinin süresi, Garantinin koşulları altında verilen hizmetler için kullanılan süre kadar uzatılacaktır.
- Garanti kapsamında herhangi bir kusur mevcut olmadıkça, Siemens değiştirme veya tamir için müşteriye fatura düzenleme hakkını saklı tutmaktadır.
- Yukarıdaki hükümler, kanıtlama yükümlülüğünde müşterinin zararına olarak bir değişiklik getirmemektedirler.

Bu Garanti kapsamında talepte bulunmak için, lütfen Siemens Mobil Ürünler Çağrı Merkeziyle irtibata geçiniz. İlgili telefon numarasını, ekli kullanım kılavuzunda bulabilirsiniz.

SAR

European Union (RTTE) and international (ICNIRP)

INFORMATION ON RF EXPOSURE / SPECIFIC ABSORPTION RATE (SAR)

THIS MODEL MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and was adopted into the European Standard EN 50360 and into other national standards. The CE mark demonstrates that the EU requirements are met.

The highest SAR value for this device when tested at the ear was **0.533 W/kg¹**. As mobile devices offer a range of functions, they can be used in positions other than the head, such as on the body. In this case, a separation distance of **1.5 cm** is required.

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the

device to ensure it only uses the minimum level required to reach the network.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you nevertheless want to reduce your exposure then you can do so by limiting the length of calls or using a 'hands-free' device to keep the mobile phone away from the head and body.

Additional Information can be found on the websites of the World Health Organization (www.who.int/emf) or Siemens (www.siemens.com/mobilephones).

1 The tests are carried out in accordance with international guidelines for testing.

Licence Agreement

This License Agreement ("Agreement") is between You and Siemens Aktiengesellschaft, Germany ("Siemens"). The Agreement authorizes You to use the Licensed Software, specified in Clause 1 below, which may be included in your phone, stored on a CD-ROM, sent to You by electronic mail or over the air, downloaded from Siemens Web pages or servers or from other sources under the terms and conditions set forth below.

Read this Agreement carefully before using your phone. By using your phone or installing, copying, and/or using the Licensed Software, You acknowledge that You have read and understood the Agreement and agree to be bound by all of the terms and conditions stated below. You further agree that if Siemens or any licensor of Siemens ("Licensor") is required to engage in any proceeding, legal or otherwise, to enforce their rights under this Agreement, Siemens and/or its Licensor shall be entitled to recover from You, in addition to any other sums due, reasonable attorney's fees, costs and disbursements. If You do not agree to all of the terms and conditions of this Agreement, do not install or use the Licensed Software. This Agreement governs any Updates, releases, revisions, or enhancements to the Licensed Software.

1. **LICENSED SOFTWARE.** As used in this Agreement, the term "Licensed Software" means collectively: all the software in Your phone, all of the contents of the disk(s), CD-ROM(s), electronic mail and its file attachments, or other media with which this Agreement is provided and includes any related Siemens or third party software and upgrades, modified versions, updates, additions and copies of the Licensed Software,

if any, distributed over the air, downloaded from Siemens Web pages or servers or from other sources.

2. **COPYRIGHT.** The Licensed Software and all related rights, without limitation including proprietary rights therein, are owned by Siemens, its Licensors or affiliates and are protected by international treaty provisions and all applicable national laws. This Agreement does not convey to You nor allow You to acquire any title or ownership interest in the Licensed Software or rights therein. The structure, organization, data and code of the Licensed Software are the valuable trade secrets and confidential information of Siemens, its Licensors or affiliates. You must reproduce and include the copyright notices with any permitted copies You make of the Licensed Software.

3. **LICENSE AND USE.** Siemens grants to You a non-exclusive, non-transferable end user right to install the Licensed Software or use the Licensed Software installed on the phone. The Licensed Software is licensed with the phone as a single integrated product and may be used with the phone only as set forth in these licensing terms.

4. **LIMITATIONS ON LICENSE.** You may not copy, distribute, or make derivative works of the Licensed Software except as follows:

(a) You may make one copy of the Licensed Software, excluding the documentation, as an archival backup copy of the original. Any other copies You make of the Licensed Software are in violation of this Agreement.

(b) You may not use, modify, or transfer the right to use the Licensed Software other than together with the accompanying hardware or copy the Licensed Software except as expressly provided in this Agreement.

(c) You may not sublicense, rent or lease the Licensed Software.

(d) You may not reverse engineer, decompile, modify, or disassemble those Licensed Software programs except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

Parts of the Licensed Software may be supplied by third parties and may be subject to separate license terms. Such terms are set out within the documentation.

5. MISUSE OF THE LICENSED SOFTWARE OR DATA GENERATED BY THE LICENSED SOFTWARE IS STRICTLY PROHIBITED BY SIEMENS, MAY VIOLATE GERMAN, U.S. AND OTHER LAWS AND MAY SUBJECT YOU TO SUBSTANTIAL LIABILITY. You are solely responsible for any misuse of the Licensed Software under this Agreement and for any liability or damage related in any way to your use of the Licensed Software in violation of this Agreement. You are also responsible for using the Licensed Software in accordance with the limitations of this Agreement.

6. TERMINATION. This Agreement is effective from the first date You install, copy or otherwise use the Licensed Software. You may terminate this license at any time by deleting or destroying the Licensed Software, all back up copies and all related materials provided to You by Siemens. Your license rights terminate automatically and immediately without notice if You fail to comply with any provision of this Agreement.

The rights and obligations under sections 2, 5, 6, 7, 9, 12 and 13 of this Agreement shall survive the termination of this Agreement.

7. YOU ACKNOWLEDGE THE LICENSED SOFTWARE IS PROVIDED "AS IS" AND NEITHER SIEMENS NOR ANY OF ITS LICENSORS MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR THAT THE LICENSED SOFTWARE WILL NOT INFRINGE ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADEMARKS OR OTHER RIGHTS. THERE IS NO WARRANTY BY SIEMENS OR ITS LICENSORS OR BY ANY OTHER PARTY THAT THE FUNCTIONS CONTAINED IN THE LICENSED SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION OF THE LICENSED SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE AND SIEMENS AND ITS LICENSORS HEREBY DISCLAIM ANY AND ALL LIABILITY ON ACCOUNT THEREOF. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY A SIEMENS REPRESENTATIVE SHALL CREATE A WARRANTY OR IN ANY WAY AFFECT THIS DISCLAIMER. YOU ASSUME ALL RESPONSIBILITY TO ACHIEVE YOUR INTENDED RESULTS AND FOR THE INSTALLATION, USE, AND RESULTS OBTAINED FROM IT.

8. NO OTHER OBLIGATIONS. This Agreement creates no obligations on the part of Siemens other than as specifically set forth herein.

9. **LIMITATION OF LIABILITY.** IN NO EVENT SHALL SIEMENS, ITS EMPLOYEES, LICENSORS, AFFILIATES OR AGENTS BE LIABLE FOR ANY DIRECT DAMAGES, LOST PROFITS, DATA OR BUSINESS, OR COSTS OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, PROPERTY DAMAGE, INTERRUPTION OF BUSINESS OR FOR ANY SPECIAL, INDIRECT, INCIDENTAL, EXEMPLARY, ECONOMIC, PUNITIVE OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED, AND WHETHER ARISING UNDER CONTRACT, TORT, NEGLIGENCE, OR OTHER THEORY OF LIABILITY, OR ARISING OUT OF THE USE OF OR INABILITY TO USE THE LICENSED SOFTWARE, EVEN IF SIEMENS IS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE LIMITATION OF LIABILITY SHALL NOT APPLY IF AND TO THE EXTENT SIEMENS' LIABILITY IS MANDATORY UNDER THE APPLICABLE LAW E.G. ACCORDING TO PRODUCT LIABILITY LAW OR IN THE EVENT OF INTENTIONAL MISCONDUCT, PERSONAL INJURY OR DEATH.

10. **TECHNICAL SUPPORT.** Siemens has and its Licensors have no obligation to furnish You with technical support unless separately agreed in writing between You and Siemens or the applicable Licensor.

Siemens and where applicable its Licensors in the Licensed Software shall be free to use any feedback received from You resulting from your access to and use of the Licensed Software for any purpose including (without limitation) the manufacture, marketing and maintenance or support of products and services.

11. **EXPORT CONTROL.** The Licensed Software may include technical data and cryptographic software and is subject to German, European Union and U.S. export controls and may be subject to import or export controls in other countries. You agree to strictly comply with all applicable import and export laws and regulations. Specifically, You agree, to the extent required by U.S. Export Administration Regulations, that You shall not disclose or otherwise export or re-export the Licensed Software or any part thereof delivered under this Agreement to (a) Cuba, Iran, Iraq, Libya, North Korea, Sudan, Syria or any other country (including a national or resident of such country) to which the U.S. has restricted or prohibited the export of goods or services.


12. **APPLICABLE LAW AND FORUM.** The laws of Germany govern this Agreement. No choice of law rules of any jurisdiction will apply. The courts in Munich shall settle any disputes arising out of or relating to this Agreement provided you are a merchant.

13. **MISCELLANEOUS.** This Agreement represents the entire agreement between You and Siemens relating to the Licensed Software and (i) supersedes all prior or contemporaneous oral or written communications, proposals, and representations with respect to its subject matter; and (ii) prevails over any conflicting or additional terms of any acknowledgement or similar communication between the parties during the term of this License. Notwithstanding the foregoing, some products of Siemens may require You to agree to additional terms through an on-line "click-wrap" license, and such terms shall supplement this Agreement. If any provision of this Agreement is held invalid, all other provisions shall remain valid unless such validity would frustrate the purpose of this Agreement, and this Agreement shall be

en-forced to the full extent allowable under applicable law. No modification to this Agreement is binding, unless in writing and signed by a duly authorized representative of each party. This Agreement shall be binding on and shall inure to the benefit of the heirs, successors, and assigns of the parties hereto. The failure of either party to enforce any right resulting from the breach of any provision of this Agreement by the other party will not be deemed a waiver of any right related to a subsequent breach of such provision or any other right hereunder. Notwithstanding anything to the contrary in this Agreement, Siemens and/or its licensors may enforce its rights, including but not limited to copyright, trademark or trade names, in accordance with the rules of law in each country.

Index

- A**
- Alarm clock..... 51
 - All calls (diversion)..... 41
 - All incoming (network barrings) 44
 - Any key to answer 41
 - Appointments..... 46
 - Auto key lock..... 43
 - Auto last number redial..... 18
 - Autom. display, clock..... 43
- B**
- Band selection 44
 - Battery
 - Charging 9
 - Inserting..... 7
 - Operating times..... 9
 - quality declaration 59
 - Big letters 37
 - Bluetooth® (BT) 38
 - Bookmarks (WAP) 34
 - Browser 35
 - Buddhist year..... 43
- C**
- Calculator 48
 - Calendar..... 46
 - Call
 - Accepting/ending 18
 - Blocked 44
 - Conference..... 19
 - Diverting 41
 - Putting on hold..... 19
 - Rejecting 18
 - Toggling (swapping)..... 19
 - Call divert 41
 - Call screening 41
 - Call waiting..... 19, 41
 - Calling 18
 - Calls received (call record)..... 23
 - Camera..... 24
 - Car Kit 45
 - Care of phone..... 59
 - CB services..... 33
 - Certificates 44
 - Charges..... 23
 - Charges/units 23
 - Charging the battery 9
 - Clock..... 43
 - Codes..... 14
 - Conference 19
 - Connection profiles 39
 - Converter 48
 - Countdown 50
 - Credit limit 23
 - Currency converter 49
 - Customer care 57
- D**
- Date format..... 43
 - Deactivating autom. phone 42
 - Device manager 42
 - Dialling code 18
 - Dialling with number keys 18
 - Dictating machine 47
 - Digital Rights Management..... 11
 - Display
 - Illumination 37
 - Symbols 6
 - Wallpaper..... 37
 - Divert..... 41
 - DTMF tones (tone sequences)..... 19
- E**
- EGPRS 38
 - E-mail..... 31
 - Receiving/reading..... 31
 - Settings 31
 - Writing..... 31
 - Emergency number 10
 - Extras..... 48
- F**
- Factory settings..... 42
 - Fast access 40
 - Flash 25
 - Frequency range 44

- H**
- Handsfree talking..... 19
 - Headset..... 45
 - Hide ID..... 41
 - Highlighting mode..... 13
 - Hotline..... 57
- I**
- Identity number (IMEI)..... 42
 - IMEI number..... 42
 - Inbox..... 28
 - International dialling code..... 18
 - Internet..... 34
 - IrDA (Infrared)..... 38
- K**
- Key tones..... 40, 42
- L**
- Last number redial..... 18
 - Licence Agreement..... 65
 - Limit (duration/charges)..... 23
 - Logo..... 37
 - Loss of phone, SIM card..... 61
- M**
- Mailbox..... 33
 - Maintenance of phone..... 59
 - Media player..... 52
 - Microphone on/off..... 25
 - Minute beep..... 41
 - Missed calls (call record)..... 23
 - MMS/SMS..... 26
 - Mobile Phone Manager..... 56
 - MultiMediaCard™..... 8, 55
 - My menu..... 50
 - My stuff..... 53
- N**
- Network
 - Barring..... 44
 - Connection..... 44
 - Settings..... 44
 - Notes..... 46
 - Numbers dialled (call record)..... 23
- O**
- Only ..... 43
 - Operating times (battery)..... 9
 - Organiser..... 46
- P**
- PC connection..... 15
 - Phone code..... 14
 - Phone data..... 61
 - Phone ID (IMEI)..... 42
 - Phone number transmission..... 41
 - PIN
 - Changing..... 14
 - Entering..... 10
 - Use..... 14
 - PIN2..... 14
 - Preferred network..... 44
 - Preventing accidental activation..... 15
 - Profiles
 - Phone..... 36
 - WAP..... 35
 - Prompt..... 18
 - Provider logo..... 37
 - PUK, PUK2..... 14
 - Putting a call on hold..... 19
- R**
- Receiving signal..... 11
 - Records..... 23
 - Reminder..... 18
 - Ringtones..... 36
- S**
- Safety precautions..... 2
 - Screensaver..... 37
 - Second phone number..... 44
 - Security..... 14
 - Service tones..... 42
 - Setting time/date..... 43
 - Settings..... 36
 - Short message (SMS)..... 26
 - Shown in the display..... 6
 - Shut down animation..... 37
 - Silent alert..... 37
 - SIM card
 - Clearing barrings..... 15
 - Inserting..... 11

SIM services (optional)	48
SMS/MMS	26
SOS	10
Sound recorder	49, 50
Special characters	16
Standard functions.....	13
Standby mode	11
Standby time	9, 61
Start up animation	37
Stopwatch	50
Switching off the phone, manual	10
Switching on (phone)	10
Symbols.....	6
Synchronisation	47

T

T9 text input.....	16
Tasks	46
Technical data	61
Text input	16
Text module	17
Themes	37
This SIM only	43
Time zones	10, 43, 47
Toggling	19
Tone sequence (DTMF)	19

U

Unanswered calls	41
Upper and lowercase letters (T9)	16
User group	44

V

Video playback	52
Voice mailbox.....	33
Volume	
Earpiece volume.....	18
Profiles.....	36
Ringtone	36

W

Wallpaper (display).....	37
WAP	34
WAP push	32